



**VoiceGenie 7.2**

**TDD/TYY**

**User's Guide**

**The information contained herein is proprietary and confidential and cannot be disclosed or duplicated without the prior written consent of Genesys Telecommunications Laboratories, Inc.**

Copyright © 2005–2006 Genesys Telecommunications Laboratories, Inc. All rights reserved.

## About Genesys

Genesys Telecommunications Laboratories, Inc., a subsidiary of Alcatel, is 100% focused on software for call centers. Genesys recognizes that better interactions drive better business and build company reputations. Customer service solutions from Genesys deliver on this promise for Global 2000 enterprises, government organizations, and telecommunications service providers across 80 countries, directing more than 100 million customer interactions every day. Sophisticated routing and reporting across voice, e-mail, and Web channels ensure that customers are quickly connected to the best available resource—the first time. Genesys offers solutions for customer service, help desks, order desks, collections, outbound telesales and service, and workforce management. Visit [www.genesyslab.com](http://www.genesyslab.com) for more information.

Each product has its own documentation for online viewing at the Genesys Technical Support website or on the Documentation Library CD, which is available from Genesys upon request. For more information, contact your sales representative.

## Notice

Although reasonable effort is made to ensure that the information in this document is complete and accurate at the time of release, Genesys Telecommunications Laboratories, Inc., cannot assume responsibility for any existing errors. Changes and/or corrections to the information contained in this document may be incorporated in future versions.

## Your Responsibility for Your System's Security

You are responsible for the security of your system. Product administration to prevent unauthorized use is your responsibility. Your system administrator should read all documents provided with this product to fully understand the features available that reduce your risk of incurring charges for unlicensed use of Genesys products.

## Trademarks

Genesys, the Genesys logo, and T-Server are registered trademarks of Genesys Telecommunications Laboratories, Inc. All other trademarks and trade names referred to in this document are the property of other companies. The Crystal monospace font is used by permission of Software Renovation Corporation, [www.SoftwareRenovation.com](http://www.SoftwareRenovation.com).

## Technical Support from VARs

If you have purchased support from a value-added reseller (VAR), please contact the VAR for technical support.

## Technical Support from Genesys

If you have purchased support directly from Genesys, please contact Genesys Technical Support at the following regional numbers:

Region	Telephone	E-Mail
North and Latin America	+888-369-5555 or +506-674-6767	<a href="mailto:support@genesyslab.com">support@genesyslab.com</a>
Europe, Middle East, and Africa	+44(0)-118-974-7002	<a href="mailto:support@genesyslab.co.uk">support@genesyslab.co.uk</a>
Asia Pacific	+61-7-3368-6868	<a href="mailto:support@genesyslab.com.au">support@genesyslab.com.au</a>
Japan	+81-3-5649-6871	<a href="mailto:support@genesyslab.co.jp">support@genesyslab.co.jp</a>

Prior to contacting technical support, please refer to the [Genesys Technical Support Guide](#) for complete contact information and procedures.

## Ordering and Licensing Information

Complete information on ordering and licensing Genesys products can be found in the [Genesys 7 Licensing Guide](#).

## Released by

Genesys Telecommunications Laboratories, Inc. [www.genesyslab.com](http://www.genesyslab.com)

**Document Version:** 09-2006



# Table of Contents

<b>Introduction</b>	<b>4</b>
1.1 Functional Overview	4
1.2 VoiceGenie Components	4
1.2.1 Media Platform (MP)	4
1.2.2 Speech Resource Management (SRM)	5
<b>2 Installation</b>	<b>5</b>
<b>3 System Configuration Overview</b>	<b>5</b>
<b>4 Media Platform Provisioning</b>	<b>6</b>
4.1 Application Development	7
4.1.1 Grammar support	7
4.1.2 Application Example	7
4.1.3 ASR Result Priority	9
4.1.4 TDD specific application properties	9
4.1.5 Limitations	10

## Introduction

Telecommunications Devices for the Deaf (TDD) devices, also known as TDD/TTY devices, enable callers to communicate over telephone lines using keyboard devices for input and output.

TDD/TTY operates entirely over the standard PSTN. Unlike a modem, TDD/TTY devices do not negotiate connectivity at the start of the call, nor do they maintain synchronization throughout a call. Rather, they generate the required tones when sending data, and do not transmit at other times.

VoiceGenie 7 has the capability to recognize TDD tones as part of a VoiceXML session. The ability is exposed as part of VoiceGenie's support for Automatic Speech Recognition (ASR).

### 1.1 Functional Overview

The VoiceGenie TDD/TTY recognition module will work with any TDD/TTY devices that support standard 5-bit baudot encoding with FSK operating at 1800Hz and 1400Hz.

Since 5-bit baudot character sets are case-insensitive, the TDD recognition engine assumes the characters accepted are all capitalized.

A typical call with the VoiceGenie platform is capable of operating in one of three modes:

- TDD/TTY disabled. This mode essentially reflects the current VoiceGenie solution; it does not detect or respond to TDD/TTY input, nor does it render any output in a TDD/TTY compatible format. Any requests by the application to collect input using TDD/TTY will be ignored.
- TDD/TTY input enabled with optional switching. In this mode, the VoiceGenie solution operates as it does currently upon receiving a call. However, it allows the application to utilize TDD/TTY to collect input. It also supports optional switching:

After X seconds (where X is a configurable value) of elapsed time, if no TDD/TTY tones have been detected, the call can switch to mode # 1 above, where TDD/TTY input is disabled.

If a TDD/TTY tone has been detected, the call can switch to mode # 3 below, where a TDD/TTY is assumed to be utilized.

- TDD/TTY only. In this mode, speech input using traditional ASR engines will be disabled; DTMF and TDD/TTY input will continue to be enabled. It will also be possible to force all output to occur using TDD/TTY, if desired by the application.

### 1.2 VoiceGenie Components

Before explaining the VoiceGenie architecture and provide examples of configurations, the following subsections describe the functionality of each VoiceGenie component. For a detailed VoiceGenie 7 system overview, please refer to the [VoiceGenie 7 Media Platform Users' Guide](#).

#### 1.2.1 Media Platform (MP)

The VoiceGenie Media Platform contains a VoiceXML interpreter that allows incoming/outgoing calls to interact with callers using VoiceXML dialogs. The Media Platform connects to Voice over IP (VoIP) networks or, using PSTN media processing boards, to TDM telephony networks.

### 1.2.2 Speech Resource Management (SRM)

The Speech Resource Management server is a component that keeps track of all Automatic Speech Recognition (ASR) and Text-to-Speech (TTS) engines and distributes requests from the Media Platform to these engines.

## 2 Installation

As a pre-requisite, the system must have the following installed:

- VoiceGenie 7 Software or later
- VoiceGenie SRM Server
- VoiceGenie TDD/TTY package

Please refer to Section 6 "ASR and TTS Software Installation" of the [VoiceGenie 7 Media Platform Users' Guide](#) for detailed instructions for how to install the TDD/TTY packages.

## 3 System Configuration Overview

The VoiceGenie TDD/TTY component is implemented as a shared object loaded by the SRMServer. The SRMServer exposes the TTY engine as an ASR resource.

Once the package is deployed successfully, the system will be configured automatically. From the Cluster Management Platform (CMP) System Management Console (SMC), the Speech Resource Manager sub-menu for the SRM Server provides access to the SRMServer configuration, as shown:

<input checked="" type="checkbox"/>	<a href="#">vrmserver.tty.audiobuffersize</a>	540
<input checked="" type="checkbox"/>	<a href="#">vrmserver.tty.enginename</a>	ttyrecognizer
<input checked="" type="checkbox"/>	<a href="#">vrmserver.tty.virtual_dir</a>	ttyrecognizer
<input checked="" type="checkbox"/>	<a href="#">vrmserver.tty.numsession</a>	36
<input checked="" type="checkbox"/>	<a href="#">vrmserver.tty.numgramthread</a>	5
<input checked="" type="checkbox"/>	<a href="#">vrmserver.tty.numthread</a>	5
<input checked="" type="checkbox"/>	<a href="#">vrmserver.tty.default.noinputtimeout</a>	10
<input checked="" type="checkbox"/>	<a href="#">vrmserver.tty.default.termdigittimeout</a>	10
<input checked="" type="checkbox"/>	<a href="#">vrmserver.tty.default.interdigittimeout</a>	10
<input checked="" type="checkbox"/>	<a href="#">vrmserver.tty.translatespace</a>	
<input checked="" type="checkbox"/>	<a href="#">vrmserver.tty.audioprocesssize</a>	1320
<input checked="" type="checkbox"/>	<a href="#">vrmserver.tty.audiothreshold</a>	8

The following table describes each of the parameters. These can be changed using the VoiceGenie SMC interface:

Parameter Name	Default Value	Description
vrmserver.tty.enginename	ttyrecognizer	The engine name to be used in the CMP health monitor
vrmserver.tty.virtual_dir	ttyrecognizer	The MRCP URI to be exposed by the SRM server for incoming ASR requests
vrmserver.tty.audiobuffersize	540	Specifies the internal audio buffer size in bytes. A smaller value results in higher accuracy and rapid response but requires more CPU resources.
vrmserver.tty.numsession	36	The maximum number of concurrent sessions that the TTY Engine will accept.
vrmserver.tty.numgramthread	5	Number of TTY Grammar Threads for the engine. This parameter depends on system performance
vrmserver.tty.numthread	5	VRMServer.TTY.numThread
vrmserver.tty.default.noinputtimeout	10	The default 'no input' timeout value in seconds
vrmserver.tty.default.termdigittimeout	10	The default 'termdigittimeout' timeout value in seconds
vrmserver.tty.default.interdigittimeout	10	The default 'interdigittimeout' timeout value in seconds
vrmserver.tty.translatespace	<empty>	The character with which to replace a space character. If this is not specified, any space character encountered will be dropped in the recognition result. This has been added to support ease of grammar matching for words like "Thank You" and "Thank You".
vrmserver.tty.audioprocesssize	1320	This is the "Jitter" buffer size (in bytes) whereby the audio stream is processed in the specified fixed size at a time.
vrmserver.tty.audiothreshold	8	The audio threshold level for echo cancellation. The recommended value is 8. Specifying a number less than 0 disables this feature. Note: This is an arbitrary level and doesn't correspond to decibels (dB).

#### 4 Media Platform Provisioning

After the TDD/TTY package has been installed, the MediaPlatform -> SpeechResources submenu will show the TDD/TTY engine as follows:

Speech Resource Name:	TTY		
Hostname/IP:	10.0.0.70	Port:	22000
Resource URI:	rtsp://10.0.0.70:22000/ttyrecognizer		
Resource Type:	ASR		
Parameter Name:	vrn.client.SendGramma	Value:	true <input type="button" value="Remove"/>
Parameter Name:	vrn.client.SendVGParar	Value:	true <input type="button" value="Remove"/>
Parameter Name:		Value:	<input type="text"/> <input type="button" value="Add"/>
<input type="button" value="Update"/> <input type="button" value="Delete"/> <input type="button" value="Target as Primary"/> <input type="button" value="Target as Backup"/>			

At this point, the user should click on "Target as Primary" button and select the server that has the Media Platform installed. Click on update.

Please note that since the TDD/TTY engine does not have an HTTP fetching capability - therefore the MP speech resource parameter "vrn.client.SendGrammarContent" must be set to true. This setup is performed automatically by the installation package already. Further to this, only in-line grammars are currently supported.

## 4.1 Application Development

The following sections describe the steps in building a TDD/TTY application:

### 4.1.1 Grammar support

The TDD/TTY engine accepts W3C GRXML as the format for defining a grammar for the recognition. An example is given below:

```
<?xml version="1.0"?>
<grammar mode="tdd" version="1.0" root="Help-dtmf"
  type="application/grammar+xml"
  xmlns="http://www.w3.org/2001/06/grammar">
  <rule id="Help-dtmf" scope="public">
    <item repeat="1-200">
      <one-of>
        <item>DICTIONARY</item>
        <item>PAPER</item>
        <item>ENGINEERING</item>
        <item>MSG</item>
      </one-of>
    </item>
  </rule>
</grammar>
```

In the example grammar above, the TTD/TTY engine will recognize any of the words PAPER, DICTIONARY, ENGINEERING, MSG, as typed by the user. Notice that the "mode" attribute must be set to "tdd" for TDD enabled grammars. If the same grammar is used for both voice and tdd recognition, then the user can specify speech as well as tdd, for example, by setting mode=" voice tdd".

### 4.1.2 Application Example

An application that performs TDD recognition will be very similar to a conventional ASR application. An example is given as follows:

```
<?xml version="1.0"?>
<vxml version="1.0">
<meta name="application" content="TDD test"/>
<property name="LOGLEVEL" value="2"/>
<property name="bargein" value="true"/>
<property name="asengine" value="TTY"/>
<property name="confidencelevel" value="0.45"/>
<property name="universals" value="none"/>
<var name="counter" expr="0"/>
<form>

  <field name="pword">
    <prompt> <audio src="tty_4wordprompt.vox"/> </prompt>
    <grammar mode="tdd" version="1.0" root="Help-dtmf"
      type="application/grammar-xml"
      xmlns="http://www.w3.org/2001/06/grammar">
      <rule id="Help-dtmf" scope="public">
        <item repeat="1-200">
          <one-of>
            <item>9</item>
            <item>8</item>
            <item>7</item>
            <item>6</item>
            <item>5</item>
            <item>4</item>
            <item>3</item>
            <item>2</item>
            <item>1</item>
            <item>0</item>
          </one-of>
        </item>
      </rule>
    </grammar>
    <catch event="noinput">
      I did not hear you
    </catch>
    <catch event="nomatch">
      I did not understand
    </catch>
    <filled>
      you said <value expr="pword"/>

      <assign name="counter" expr="counter+1"/>

      <if cond="counter==4">
        <disconnect/>
      <else/>
        <clear namelist="pword"/>
        <reprompt/>
      </if>

    </filled>
  </field>
</form>
</vxml>
```

In the above example, the user can input a digit string containing any of the digits from 0 to 9 – the length of the digit string can vary from 1 to 200 digits.



For TDD devices that support dual voice/TDD input modes, the application must play a TDD prompt to "trigger" the device to operate in TDD mode. In the example given, the "tty\_4wordprompt.vox" is an audio file (ulaw format) that contains the TDD Prompt.

**4.1.3 ASR Result Priority**

The priority for the TDD and ASR results can be configured through the SMC, using the "Configuration -> Media Platform" submenu. By default, they have the following values:

```
speech_asengine_priority = 1
tdd_engine_priority = 0
```

The priority scheme is useful when simultaneous Speech / TDD recognition sessions occur. It determines whether to wait for ASR result before stopping the TDD recognition engine.

For ASR engines with priority 0, when a "start-of-speech" event comes from the engine, it will stop recognition on all the other engines, including other engines with priority 0. For ASR engines with priority n greater than 0, when a "start-of-speech" event comes from the engine, it will stop recognition on all the other engines with priority greater than n, *but recognition will continue on engines with priority equal to n.*

By setting the tdd\_engine\_priority to be higher than the normal speech recognition engine, it allows the TDD recognition to continue when a start-of-speech is detected from the normal ASR engine. This is useful because if the ASR Engine is using energy-based start-of-speech detection, it will generate a start-of-speech even when the user inputs TDD tones.

In normal scenarios, this priority setting does not need to be changed.

**4.1.4 TDD specific application properties**

To enable the TDD specific application properties, the following properties must be set in the VoiceXML application:

```
<property name="com.voicegenie.TDDPARAMINUSE" value="true"/>
```

The following properties are supported:

Parameter name	Description
com.voicegenie.tddtermchar	A termchar must be non-empty when specified, and is entered by the user before the tddinterdigittimeout expires, to signify that the users input is complete; the termchar is not included as part of the recognized value
com.voicegenie.tddtermdigittimeout	If the entry of the last character input has brought the grammar to a termination point at which no additional character is allowed by the grammar, then the tddtermdigittimeout may be used in the following scenario:  If the tddtermdigittimeout is 0s (the default), then the recognized value is returned immediately after the last DTMF allowed by the grammar, without waiting for the optional termchar.

	If tddtermdigittimeout is not 0 and if the termchar is non-empty, then the user can enter an optional termchar DTMF. If the user fails to enter this optional DTMF within termtimeout, the recognition ends and the recognized value is returned
com.voicegenie.tddinterdigittimeout	The interdigittimeout determines when the nomatch event is thrown because a TDD grammar is not yet recognized, and the user has failed to enter additional input

#### 4.1.5 Limitations

Following are the set of known limitations for the TDD/TTY implementation:

- Grammars must be defined inline with the MRCP DEFINE-GRAMMAR request, as the TTY engine does not have a fetching module
- Only simple DTMF-style XML grammars are supported currently.
- URI references using rules are not supported (i.e., URI in the form of `http://<grammar name>#<rulename>`)
- External rule references inside the grammar are not supported
- The grammar matcher class does not perform DTD validation on the grammar
- The TDD/TTY engine does not support lexicon definitions or references;
- The TDD/TTY engine supports only characters that can be defined in the standard baudot encoding
- The VoiceGenie Platform supports both per-utterance and per-call ASR sessions. The TDD/TTY engines supports only the per-call mode. TTY phones do not send FIGS & LTRS mode information with each character, so mode information will be lost in a per-utterance scenario. For FIGS mode (0-9 and space only), both per-call and per-utterance modes are supported.
- Sometimes when the user barges in, the TDD device will still display the remainder of the prompt. This is due to buffering of received TDD audio prior to display
- The recognition performance is known to degrade as the TDD input length increases, especially if the user enters a long series of TDD inputs.