



This PDF is generated from authoritative online content, and is provided for convenience only. This PDF cannot be used for legal purposes. For authoritative understanding of what is and is not supported, always use the online content. To copy code samples, always use the online content.

Outbound Contact

Call Progress Detection Server

12/17/2025

Call Progress Detection Server

Options for this component are contained in the following configuration sections:

- [general](#)
- [hmp](#)
- [isdn](#)
- [line-side](#)
- [tones](#)

Tip

In the summary table(s) below, type in the Search box to quickly find options, configuration sections, or other values, and/or click a column name to sort the table. Click an option name to link to a full description of the option. Be aware that the default and valid values are the values in effect with the latest release of the software and may have changed since the release you have; refer to the full description of the option to see information for earlier releases.

Power users: [Download a CSV file](#) containing default and valid values and descriptions.

The following options are configured at the application level (in other words, on the application object).

Section	Option	Default	Changes Take Effect
general	continuous-no-signal	20	Takes effect immediately
general	conversation-file-name-prefix	conv_	Takes effect after restart
general	cpd-file-name-prefix	cpd_	Takes effect after restart
general	cpd-if-established	false	Takes effect immediately
general	cpd-recording	false	Takes effect immediately
general	destination-busy-timeout	2000	Takes effect immediately
general	keep-channels-open	false	Takes effect immediately
general	line-type		Takes effect after restart
general	location		Takes effect after restart
general	max-number-ports-to-	0	Takes effect
Section	Option	Default	Changes Take Effect

Section	Option	Default	Changes Take Effect
	record		immediately
general	off-hook-delay	-1	Takes effect immediately
general	off-hook-timeout	1	Takes effect immediately
general	on-hook-timeout	1	Takes effect immediately
general	out-of-service-attempts	2	Takes effect immediately
general	out-of-service-timeout	1	Takes effect immediately
general	post-connect-cpd-priority	tserver	Takes effect immediately
general	pre-connect-cpd-priority	tserver	Takes effect immediately
general	sit-detection	true	Takes effect immediately
general	tscall	false	Takes effect immediately
general	tsclear	false	Takes effect immediately
general	use-busy2-as-nu-tone	false	Takes effect immediately
general	use-engaging-lines	false	Takes effect after restart
general	use-fax2-as-am-tone	false	Takes effect immediately
general	wait-off-hook	false	Takes effect after restart
hmp	audio-codecs	PCMU	Takes effect after restart
hmp	engage-cpd-on-call-setup	false	Takes effect immediately
hmp	sip-proxy		Takes effect after restart
isdn	called-party-number-plan	isdn	Takes effect immediately
isdn	called-party-number-type	national	Takes effect immediately
isdn	calling-party-number		Takes effect immediately
isdn	calling-party-number-plan	isdn	Takes effect immediately
isdn	calling-party-number-type	national	Takes effect immediately
isdn	engage-cpd-on-call-setup	false	Takes effect immediately
Section	Option	Default	Changes Take Effect

Section	Option	Default	Changes Take Effect
isdn	isdn-trace	false	Takes effect immediately
isdn	isdn-trace-file-name-prefix	isdn_	Takes effect immediately
isdn	presentation-indicator	restricted	Takes effect immediately
isdn	use-channel-state	false	Takes effect immediately
isdn	user-info-layer-1	g711-ulaw	Takes effect immediately
line-side	off-hook-bit-mask	a-on;b-on;	Takes effect immediately
line-side	on-hook-bit-mask	a-off;b-on;	Takes effect immediately
line-side	rcv-idle-bit-mask	a-off;b-on;	Takes effect immediately
line-side	snd-idle-bit-mask	a-off;b-on;	Takes effect immediately
tones	busy-tone-1	500;200;0;0;55;40;55;40;4	Takes effect immediately
tones	busy-tone-2	500;200;500;200;55;40;55;40;4	Takes effect immediately
tones	disconnect-tone	500;200;500;200;55;40;55;40;10	Takes effect immediately
tones	extra-dial-tone	401;125;401;125;0;0;0;0;0	Takes effect immediately
tones	fax-tone-1	2150;150;0;0;25;-25;0;0;0	Takes effect immediately
tones	fax-tone-2	1100;50;0;0;25;-25;0;0;0	Takes effect immediately
tones	forth-tone	0;0;0;0;0	Takes effect immediately
tones	intl-dial-tone	402;125;402;125;0;0;0;0;0	Takes effect immediately
tones	local-dial-tone	400;125;400;125;0;0;0;0;0	Takes effect immediately
tones	ring-back-tone-1	450;150;0;0;130;105;580;415;0	Takes effect immediately
tones	ring-back-tone-2	450;150;450;150;130;105;580;415;0	Takes effect immediately
tones	sit-tone	900;1000;5;50;0;0;0;0;0;0	Takes effect immediately
Section	Option	Default	Changes Take Effect