

GENESYS

This PDF is generated from authoritative online content, and is provided for convenience only. This PDF cannot be used for legal purposes. For authoritative understanding of what is and is not supported, always use the online content. To copy code samples, always use the online content.

SIP Cluster Solution Guide


Deploying SIP Cluster

Deploying SIP Cluster

Important

SIP Cluster solution is under restricted availability. Contact Product Management for more information.

The SIP Cluster for Premise deployments typically involve two or more data centers in geographically distinct locations. Some components are designed to operate in a geo-dispersed manner while others need to be deployed in more traditional local or disaster recover modes. The Cluster deployment involves several different areas or layers of functionality. The following diagram depicts those deployment layers.



Cluster Deployment Layers (click to expand)

Task Summary

The following task summary provide an overview of the steps that are required to deploy the SIP Cluster solution:

- 1. Complete prerequisites, including planning, hardware, and installation of Management Framework software and supported applications.
- 2. Plan and configure DNS records.
- 3. Verify that you have the required minimum Genesys component versions.
- 4. Configure Genesys Voice Platform components.
- 5. Configure Switch and DN objects.
- 6. Configure the cluster core components:
 - SIP Server
 - SIP Proxy

- SIP Feature Server
- Stat Server
- URS and ORS
- 7. Configure Virtual Queue (VQ) components:
 - Switch and DN objects
 - SIP Server
- 8. Deploy the supported applications that you selected during the planning stage, which might include:
 - Historical Reporting
 - Outbound Contact
 - Web Services and Applications
 - Genesys Mobile Services